



FIT BLINDS IN SECONDS WITH GRIP FIT™

NO DRILL | NO SCREWS | NO FUSS



1 Raise the cassette into position



2 Press levers to secure in place



3 Fit blind into cassette

INSTALLING YOUR ROLLER BLINDS COULDN'T BE EASIER.

- Grip Fit® roller blinds only take seconds to fit and require no tools.
- No drill holes or screws required for a quick, no mess installation.
- Leaves no damage to the window recess or walls.
- Ideal for the home, office or rented accommodation where drilling into walls might not be permitted.
- Can be used for both motorised and chain operated roller blinds.

SCAN ME!



For more information contact us

+905-475-8235 | Toll free: 1-800-668-8235 | info@shadex.com | www.shadex.com

SHADEX®
DISTINCTIVE WINDOW COVERINGS